

ASX






VEILIGHEIDSHANDLEIDING MITSUBISHI ASX HEV & PHEV

INFORMATIE VOOR EERSTE- EN TWEEDELIJNSHULPDIENSTEN

MODELJAAR 2023






	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
	Automatic rollover protection system		Gas strut / Preloaded spring		High strength zone		Zone requiring special attention		
	Battery low voltage		Ultra-capacitor, low-voltage		Fuel tank		Gas tank		Safety valve
	Battery pack, high-voltage		High voltage power cable		High voltage device that disconnects high voltage		Fuse box disabling high voltage		High voltage ultra-capacitor


	ID No.	Version No.	Version Date.	Page
	RS-HJB HEV-ENRS-EN01	01	03/2023	1/4

1. Identification / recognition




2. Immobilisation / stabilisation / lifting

Engine shutdown




Forbidden wedge area



Orange cables area

3. Disable direct hazards / safety regulations

12 Volts Battery




In case of airbag release, the 12V battery automatically turns off

	ID No.	Version No.	Version Date.	Page
	RS-HJB HEV-ENRS-EN01	01	03/2023	2/4

200 Volts battery

Only if cutting operation is necessary :


Disconnection of the 200 Volts battery by removing the service plug.





4. Access to the occupants



Steering column :
Hollow and breakable with tools



HARDENED STEEL



	ID No. RS-HJB HEV-ENRS-EN01	Version No. 01	Version Date. 03/2023	Page 3/4
--	--------------------------------	-------------------	--------------------------	-------------

5. Stored energy / liquids / gases / solids

	Lithium-ion	1.2 kW.h	200 V
	 	46 L	

6. In case of fire


Extinguishing a traction battery fire propagation



TAILGATE GAS STRUTS



Risk of missile effect of gas struts



7. In case of submersion




No electrical hazard

10. Explanation of pictograms used

 Hybrid Electric Vehicle on fuel of liquid group 2				
	Remove smart key		Boot	 Use thermal Infrared camera
	Flammable		Hazardous to the human health	 Environmental hazard
Electrical protection gloves	Face shield	Breathing apparatus (BA)	Use water to extinguish the fire	Don't brake, nor open
				

	ID No.	Version No.	Version Date.	Page
	RS-HJB HEV-ENRS-EN01	01	03/2023	4/4



	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
	Automatic rollover protection system		Gas strut / Preloaded spring		High strength zone		Zone requiring special attention		
	Battery low voltage		Ultra-capacitor, low-voltage		Fuel tank		Gas tank		Safety valve
	Battery pack, high-voltage		High voltage power cable		High voltage device that disconnects high voltage		Fuse box disabling high voltage		High voltage ultra-capacitor

1. Identification / recognition




2. Immobilisation / stabilisation / lifting

Engine shutdown




Forbidden wedge area



Orange cables area

3. Disable direct hazards / safety regulations

12 Volts Battery



In case of airbag release, the 12V battery automatically turns off





	ID No.	Version No.	Version Date.	Page
	RS-HJB PHEV-ENRS-EN01	01	03/2023	2/4

400 Volts battery




Only if cutting operation is necessary :

Disconnection of the 400 Volts battery by removing the service plug.



4. Access to the occupants



Steering column :
Hollow and breakable with tools

5. Stored energy / liquids / gases / solids


	Lithium-ion	9.8 kW.h	400 V
---	-------------	----------	-------

	E5 E10	39 L
--	--------	------

	ID No.	Version No.	Version Date.	Page
	RS-HJB PHEV-ENRS-EN01	01	03/2023	3/4

6. In case of fire

Extinguishing a traction battery fire propagation




If traction battery on fire : → Water extinguishing by filling

TAILGATE GAS STRUTS



Risk of missile effect of gas struts



7. In case of submersion



No electrical hazard

10. Explanation of pictograms used

 Hybrid Electric Vehicle on fuel of liquid group 2				
 Remove smart key		 Boot		 Use thermal Infrared camera
 Flammable		 Hazardous to the human health		 Environmental hazard
Electrical protection gloves 	Face shield 	Breathing apparatus (BA) 	Use water to extinguish the fire 	Don't brake, nor open 

	ID No.	Version No.	Version Date.	Page
	RS-HJB PHEV-ENRS-EN01	01	03/2023	4/4